

INDUSTRIAL FITTINGS - fittings, connectors

Brass connectors - EW type

Working press.: Up to 40 bar

Working temp.: From -10°C up to +90°C

Hose fitting, BSP female, fixed nut



| code | thread size [inch] | hose I.D. [mm] | spanner size [mm] |
|-------------|--------------------|----------------|-------------------|
| EW-MS-11309 | 1/8 | 4 | 12 |
| EW-MS-11310 | 1/8 | 6 | 12 |
| EW-MS-13311 | 1/8 | 9 | 14 |
| EW-MS-11312 | 1/4 | 4 | 17 |
| EW-MS-11313 | 1/4 | 6 | 17 |
| EW-MS-11314 | 1/4 | 9 | 17 |
| EW-MS-11315 | 1/4 | 13 | 17 |
| EW-MS-11316 | 3/8 | 6 | 19 |
| EW-MS-11317 | 3/8 | 9 | 19 |
| EW-MS-11318 | 3/8 | 13 | 19 |
| EW-MS-11319 | 1/2 | 6 | 24 |
| EW-MS-11320 | 1/2 | 9 | 24 |
| EW-MS-11321 | 1/2 | 13 | 24 |
| EW-MS-11322 | 3/4 | 9 | 32 |
| EW-MS-11323 | 3/4 | 13 | 32 |
| EW-MS-11324 | 3/4 | 19 | 32 |
| EW-MS-11331 | 1 | 19 | 36 |
| EW-MS-11332 | 1 | 25 | 36 |
| EW-MS-11333 | 1 | 32 | 36 |

Hose fitting, BSP female, swivel nut



| code | thread size [inch] | hose I.D. [mm] | spanner size [mm] |
|---------------|--------------------|----------------|-------------------|
| EW-MS-K-02-04 | 1/8 | 4 | 12 |
| EW-MS-K-02-06 | 1/8 | 6 | 12 |
| EW-MS-K-04-04 | 1/4 | 4 | 17 |
| EW-MS-K-04-06 | 1/4 | 6 | 17 |
| EW-MS-K-04-09 | 1/4 | 9 | 17 |
| EW-MS-K-06-04 | 3/8 | 4 | 19 |
| EW-MS-K-06-06 | 3/8 | 6 | 19 |
| EW-MS-K-06-09 | 3/8 | 9 | 19 |
| EW-MS-K-08-06 | 1/2 | 6 | 24 |
| EW-MS-K-08-09 | 1/2 | 9 | 24 |
| EW-MS-K-08-13 | 1/2 | 13 | 24 |

Hose fitting with ball end (insert)



| code | nut size [inch] | hose I.D. [mm] |
|---------------|-----------------|----------------|
| EW-MS-W-02-04 | 1/8 | 4 |
| EW-MS-W-02-06 | 1/8 | 6 |
| EW-MS-W-04-04 | 1/4 | 4 |
| EW-MS-W-04-06 | 1/4 | 6 |
| EW-MS-W-04-09 | 1/4 | 9 |
| EW-MS-W-06-04 | 3/8 | 4 |
| EW-MS-W-06-06 | 3/8 | 6 |
| EW-MS-W-06-09 | 3/8 | 9 |
| EW-MS-W-08-06 | 1/2 | 6 |
| EW-MS-W-08-09 | 1/2 | 9 |
| EW-MS-W-08-13 | 1/2 | 13 |

Hose fitting, BSP male, 45° internal cone



| code | thread size [inch] | hose I.D. [mm] | spanner size [mm] |
|--------------|--------------------|----------------|-------------------|
| EW-MS-11341 | 1/8 | 4 | 14 |
| EW-MS-11351 | 1/8 | 6 | 14 |
| EW-MS-13352 | 1/8 | 9 | 14 |
| EW-MS-11368 | 1/4 | 4 | 17 |
| EW-MS-11331A | 1/4 | 6 | 17 |
| EW-MS-11340A | 1/4 | 9 | 17 |
| EW-MS-11371 | 1/4 | 13 | 17 |
| EW-MS-11332A | 3/8 | 6 | 17 |
| EW-MS-11334A | 3/8 | 9 | 17 |
| EW-MS-11343 | 3/8 | 13 | 19 |
| EW-MS-11367 | 1/2 | 6 | 24 |
| EW-MS-11366 | 1/2 | 9 | 24 |
| EW-MS-11344 | 1/2 | 13 | 24 |
| EW-MS-11325 | 3/4 | 9 | 32 |
| EW-MS-11326 | 3/4 | 13 | 32 |
| EW-MS-11327 | 3/4 | 19 | 32 |
| EW-MS-11328 | 1 | 19 | 36 |
| EW-MS-11329 | 1 | 25 | 36 |
| EW-MS-11330 | 1 | 32 | 36 |

Hexagonal nut



| code | thread size [inch] | spanner size [mm] |
|--------------|--------------------|-------------------|
| EW-MS-N-02 | 1/8 | 12 |
| EW-MS-N-04 | 1/4 | 17 |
| EW-MS-N-06 | 3/8 | 19 |
| EW-MS-N-06LH | 3/8 (left thread) | 19 |
| EW-MS-N-08 | 1/2 | 24 |