





# INSTRUMENTATION - connectors


## Threaded connectors


Cross with NPT female thread	
	
<b>102H</b>	
code	thread size [inch]
HM-P102H-02-SS	1/8
HM-P102H-04-SS	1/4
HM-P102H-06-SS	3/8
HM-P102H-08-SS	1/2
HM-P102H-12-SS	3/4
HM-P102H-16-SS	1

Reducing connector with NPT female thread		
		
<b>119H</b>		
code	thread size [inch]	thread size [inch]
HM-P119H-04-02-SS	1/4	1/8
HM-P119H-06-04-SS	3/8	1/4
HM-P119H-08-02-SS	1/2	1/8
HM-P119H-08-04-SS	1/2	1/4
HM-P119H-08-06-SS	1/2	3/8
HM-P119H-12-04-SS	3/4	1/4
HM-P119H-12-08-SS	3/4	1/2
HM-P119H-16-08-SS	1	1/2
HM-P119H-16-12-SS	1	3/4

Cap with NPT female thread	
	
<b>108H</b>	
code	thread size [inch]
HM-P108H-02-SS	1/8
HM-P108H-04-SS	1/4
HM-P108H-06-SS	3/8
HM-P108H-08-SS	1/2
HM-P108H-12-SS	3/4
HM-P108H-16-SS	1

90° reducing elbow with NPT thread (female / male)		
		
<b>116H</b>		
code	female thread size [inch]	male thread size [inch]
HM-P116H-01-01-SS	1/16	1/16
HM-P116H-02-01-SS	1/8	1/16
HM-P116H-02-02-SS	1/8	1/8
HM-P116H-04-02-SS	1/4	1/8
HM-P116H-04-04-SS	1/4	1/4
HM-P116H-06-04-SS	3/8	1/4
HM-P116H-06-06-SS	3/8	3/8
HM-P116H-08-04-SS	1/2	1/4
HM-P116H-08-06-SS	1/2	3/8
HM-P116H-08-08-SS	1/2	1/2
HM-P116H-12-12-SS	3/4	3/4
HM-P116H-16-16-SS	1	1

Connector with NPT female thread	
	
<b>103H</b>	
code	thread size [inch]
HM-P103H-02-SS	1/8
HM-P103H-04-SS	1/4
HM-P103H-06-SS	3/8
HM-P103H-08-SS	1/2
HM-P103H-12-SS	3/4
HM-P103H-16-SS	1

Plug with NPT male thread	
	
<b>107H</b>	
code	thread size [inch]
HM-P107H-04-SS	1/4
HM-P107H-06-SS	3/8
HM-P107H-08-SS	1/2